INFORCE WML™ WHITE/IR
MULTI-FUNCTION WEAPON MOUNTED LIGHT

INFORCE®

The INFORCE WML White/IR produces 200 lumens of penetrating white light with a tight beam for close to mid-range applications and balanced peripheral light for discernment of the surrounding area. It a features field-programmable strobe disable function. A thumb-action twist of the mode selection switch provides 75 mW of infrared light, with no need of IR filters. Its angled activation button is comfortable to operate without interference of wires from tape switches. Manufactured of fiber composite, the INFORCE WML White/IR is ultralight and durable; its patented venting system reduces heat for better LED performance. Superior LED technology within is virtually indestructible. O-rings seal the light to protect it from water, dust and dirt, even under extreme conditions. Its integrated NAR/MIL-STD-1913 rail-compatible mounting system is compact and secure; no tools are required. Two distinct easy-to-use locking systems are incorporated to avoid accidental discharge.

WHITE LIGHT OUTPUT:
200 lumens

RUN TIME:
1.5 hours

IR OUTPUT:
850 nm / 75 mW

RUN TIME:
3h 30min

MULTI-FUNCTION BUTTON / ACTIVATION SWITCH FEATURES:

- Constant, Momentary and Strobe
- Strobe Disable
- Constant
- Momentary

INTEGRATED MOUNTING SYSTEM is compact, convenient, and secure. NAR/MIL-STD 1913 rail compatible. No tools needed.

ANGLED ACTIVATION SWITCH is comfortable and easy to operate without interference of wires from tape switches.

(2) LOCKOUT SYSTEMS:
- Safety Lever
- Head Rotation

Bezel Diameter: 1 in. / 2.54 cm.
Length: 4.1 in. / 10.41 cm.
Weight: 3 oz. / 85.04 g.

Additional Features and Benefits:

(1) Lithium 123A Battery Included

MIL-STD-810G Tested and Certified

FIBER COMPOSITE BODY is ultralight and durable.

PATENTED HEAT-RELEASING VENTS maximize LED performance and keep the light cool.

HIGH-EFFICIENCY EMITTERS provide longer run times and are virtually immune to failure.

HIGH-IMPACT WINDOW

WATERPROOF to 66 feet.

Head removes for battery replacement.

CAUTION: Do not use counterfeit or inferior-quality batteries, as they do not meet safety and performance standards and have been the cause of personal and property damage. To ensure safety and performance, the purchase of established brands, such as Duracell,® Energizer® or Panasonic® is recommended.

ITEM NUMBER	BODY COLOR	LED
INF-WML-B-WIR	Black	White
INF-WML-F-WIR	Flat Dark Earth	White

©2015 EMISSIVE ENERGY CORP. An ISO9001:2008 Certified Company.
135 Circuit Drive, North Kingstown, RI 02852; Tel: 401-294-2030; Fax: 401-294-2050; **www.inforce-mil.com**

INFORCE and EMISSIVE ENERGY are registered trademarks of Emissive Energy Corp. WML and the distinctive shapes, styles, packaging configurations and overall appearances of INFORCE lighting systems are trademarks of Emissive Energy Corp. Designed and manufactured under one or more of the following U.S. patents: 6,966,677; 7,121,680; 7,153,004; 7,652,303; D526,730; D565,220; D596,329. European: 467295-0001; 467295-0002. **Other U.S. and International patents are pending.**

Designed and assembled in the U.S.A. of domestic and foreign components. INFORCE products qualify as "American Made" under the Buy American Act.

BATTERY REPLACEMENT

Your INFORCE WML/IR light comes with one high-efficiency 123A Lithium battery.

To insert the battery:

1. Unscrew the head to remove it from the body.
2. Insert the battery into the open body, positive (+) end first.
3. Re-thread the head onto the body.



CAUTION: Lithium batteries can explode or cause burns if recharged, shorted, disassembled or exposed to water, high temperatures or fire. Please follow the manufacturer's guidelines for safe storage, use and disposal.

If the light has been submerged, dry the exterior of the light prior to replacing the batteries. Fresh and salt water will damage internal electronics and batteries. Do not use counterfeit or inferior-quality batteries, as they do not meet safety and performance standards and have been the cause of personal and property damage. To ensure safety and performance, the purchase of established brands such as Duracell,® Energizer® or Panasonic® is recommended.

NOTE: Batteries can leak and may cause damage to the inside of the light. Remove the battery if the light will be stored for more than 2 weeks.

MAINTENANCE/CLEANING INSTRUCTIONS

Your INFORCE WML/IR light has been designed to provide maximum performance with minimum maintenance. Occasionally clean threads (1) and head and internal contact surfaces (2) with an alcohol swab and apply a thin coat of silicon-based lubricant to the rubber O-ring (3); see illustration. Do not use a petroleum-based lubricant. Should the light become dirty from dust, sand or caked-on mud, rinse the fully assembled light with water and dry with a soft cloth.



INFORCE®

WML/IR WEAPON MOUNTED LIGHT
USER MANUAL

CE

©2014 Emissive Energy Corp. Emissive Energy Corp., 135 Circuit Drive, North Kingstown, RI 02852 USA; Tel: 401-294-2030; Fax: 401-294-2050; **www.inforce-mil.com**

The distinctive shapes, styles, packaging configurations and overall appearances of all INFORCE flashlights and lighting products are trademarks of EMISSIVE ENERGY CORP.

Designed and manufactured under one or more of the following U.S. and International patents: U.S.: 6,966,677; 7,121,680; 7,153,004; 7,226,183; 7,517,108; 7,652,303; 7,784,963; D674,858; D526,730; D565,220; D579,201; D596,329; D619,283. European: 467295-0001; 467295-0002. **Other U.S. and International patents are pending.**

Designed and assembled in the U.S.A. of domestic and foreign components. This product qualifies as "American Made" under the Buy American Act.

PI-INF-ZF-WML-IR/141306

INFORCE WML/IR MOUNTING SYSTEM – PATENT PENDING

TO ATTACH THE LIGHT

1. Loosen the screw.
2. Press on the clamp to open its jaw and attach the light to the rail.
3. Finger tighten the screw; no tools are required.

TO REMOVE THE LIGHT

Loosen the screw, apply pressure to the clamp and remove the light from the rail.



INFORCE WML/IR MULTI-FUNCTION MODELS

Your INFORCE WML/IR has a patent pending multifunction switch with constant on and momentary functions plus a strobe mode. It also gives you the ability to disable the strobe feature.

WHITE LIGHT SWITCH OPERATION

For white light mode, the LED selection lever must be in position (A), with the white dot visible; see illustration on the right.

- For **momentary** mode, press and hold the button/pressure switch for more than 1/2 second; when released, the light will turn off.
- For **constant on** mode, press the button/pressure switch once. If the light is on for more than 2 seconds, the next press of the button will turn the light off. In constant mode, the light can also be used as a momentary light. Press and hold the button/pressure switch for more than 1/2 second to turn the light on. When the button is released, the light will turn off.
- For **strobe** mode, two quick presses of the button/pressure switch when in constant on or off settings will activate the strobe.

TO DISABLE THE STROBE FUNCTION

1. Unscrew the light head one revolution to the lockout position.
2. Press and hold the button/pressure switch.
3. While holding the button/pressure switch, tighten the head and then release the button. The strobe feature is now disabled.
4. To reactivate the strobe function, repeat steps 1, 2 and 3.

INFRARED LIGHT SWITCH OPERATION

For IR light mode, the LED selection lever must be in position (B); see illustration below.

The IR mode has constant on and momentary functions and has no strobe. Operation of the IR settings is identical to the white switch instructions:

- For **momentary** mode, press and hold the button/pressure switch for more than 1/2 second; when released, the light will turn off.
- For **constant on** mode, press the button/pressure switch once. If the light is on for more than 2 seconds, the next press of the button will turn the light off.

WML/IR, LED Selection Lever in Position (A) for White Beam

WML/IR, LED Selection Lever in Position (B) for IR Beam

LOCKOUT SYSTEMS

Two distinct lockout systems have been incorporated to avoid accidental discharge when carrying the light:

Option 1. A patent pending safety lever protects the activation button. Lift the safety lever to cover the button/pressure switch when not in use and lower it for light activation.

Option 2. Lock out by unscrewing the light head one revolution.

Safety Lever and Head Lockout Systems